

**WAGNER INDUSTRIES INC.  
ANVIL COVER  
CROSS REFERENCE CHART**

<u>SAUER</u>	<u>C.U.E.</u>	<u>DOVEY</u>	<u>WAGNER</u>
102	2412	DJ-10375	B-10375
108	2310	DA-10533	A-10533
109	2320	DB-9812	H-9812
142	1210	DJ-7875	B-7875
145	11416	DA-8210	A-8210
146	* 1	* 1	* 1
147	11426	N/A	N/A
148	N/A	N/A	K-8210
149	* 1	* 1	SA/SB
208	2310	DA-10533	A-10533
209	2351	N/A	E-10533
210	2320	DB-10533	H-10533
211	2330	DL-10533	K-10533
212	5212	DJ-14078	B-14078
213	5251	N/A	E-14078
214	5221	DE-14078	I-13812
215	5231	DC-14078	J-14078
216	2330	DL-10533	K-10533
238	* 1	* 1	* 1
257	3325	N/A	L-10845
258	4325	N/A	M-12775
389	8310	DA-9110	A-9110
390	8350	N/A	D-9110
391	5320	DB-9110	H-9110
392	8330	DL-9110	K-9110
393	8210	DA-10250	A-10250
394	8250	N/A	D-10250
395	8220	DB-10250	H-10250
397	2110	DA-10860	A-10860
398	2151	N/A	E-10860
399	2120	DB-10860	H-10860

\* 1 - Cross reference has not been verified. If possible, get rib structure and anvil diameter.

**WAGNER INDUSTRIES INC.  
ANVIL COVER  
CROSS REFERENCE CHART**

<u>SAUER</u>	<u>C.U.E.</u>	<u>DOVEY</u>	<u>WAGNER</u>
400	2130	DL-10860	K-10860
401	3210	DA-11280	A-11280
402	3250	N/A	D-11280
403	3220	DB-11280	H-11280
404	3230	DL-11280	K-11280
412	6112	DJ-16173	B-16173
413	6151	N/A	E-16173
414	6121	DE-16173	I-16173
415	6131	DC-16173	J-16173
590	3310	DA-11000	A-10960
591	3350	N/A	D-11000
592	3320	DB-11000	H-11000
593	3330	DL-11000	K-10960
598	3110	DA-11690	A-11690
599	3150	N/A	D-11690
600	3120	DB-11690	H-11690
601	3130	DL-11690	K-11690
606	5112	DJ-14250	B-14250
607	5150	N/A	E-14250
608	5121	DE-14250	I-14250
609	5131	DC-14250	J-14250
610	5412	DJ-13620	B-13620
611	5451	N/A	E-13620
612	5421	DE-13620	I-13620
613	5431	DC-13620	J-13620

**WAGNER INDUSTRIES INC.  
ANVIL COVER  
CROSS REFERENCE CHART**

<u>SAUER</u>	<u>C.U.E.</u>	<u>DOVEY</u>	<u>WAGNER</u>
817	10721	DE-17950	I-17950
860	6221	DE-15534	I-15534
867	6212	DJ-15534	B-15534
868	6251	N/A	E-15534
869	6221	DE-15534	I-15534
870	6251	N/A	E-15534
901	3112	DJ-11690	B-11690
902	3151	N/A	E-11690
903	3121	DE-11690	I-11690
904	3131	DC-11690	J-11690
925	* 1	* 1	A-7962S
977	6325		UA/UB
992	8330	DL-9110	K-9110
1010	3310	DA-11000	A-11000
1011	3350	N/A	D-11000
1012	3320	DB-11000	H-11000
1013	3330	DL-11000	K-11000
1050	4612	DJ-12500	B-12500
1051	4651	N/A	E-12500
1052	4621	DE-12500	I-12500
1053	4631	DC-12500	J-12500
1054	4612	DJ-12500	B-12500
1057	4631	DC-12500	J-12500
1096	6212	DJ-15534	B-15534
1097	6251	N/A	E-15534
1098	6221	DE-15534	I-15534
1099	6231	DC-15534	J-15534

\* 1 - Cross reference has not been verified. If possible, get rib structure and anvil diameter.

**WAGNER INDUSTRIES INC.  
ANVIL COVER  
CROSS REFERENCE CHART**

<u>SAUER</u>	<u>C.U.E.</u>	<u>DOVEY</u>	<u>WAGNER</u>
1102	6312	DJ-15250	B-15250
1103	6351	N/A	E-15250
1104	6321	DE-15250	I-15250
1105	6331	DC-15250	J-15250
1119	1110	DA-8210	A-8210
1120	1120	DB-8210	H-8210
1121	1150	N/A	D-8210
1122	1130	DL-8210	K-8210
1159	3110	DA-11690	A-11690
1182	4512	DJ-11960	B-11960
1234	N/A	N/A	I-15187
1241	4351	N/A	E-12800
1243	4321	DE-12800	I-12800
1244	4330	DL-12800	K-12800
1262	6312	DJ-15250	B-15250
1263	6351	N/A	E-15250
1264	6321	DE-15250	I-15250
1265	* 1	* 1	* 1
1266	4512	DJ-11960	B-11960
1267	4551	N/A	E-11960
1268	4521	DE-11960	I-11960
1310	2110	DA-10860	A-10860
1312	3320	DB-11000	H-11000

\* 1 - Cross reference has not been verified. If possible, get rib structure and anvil diameter.

**WAGNER INDUSTRIES INC.  
ANVIL COVER  
CROSS REFERENCE CHART**

<u>SAUER</u>	<u>C.U.E.</u>	<u>DOVEY</u>	<u>WAGNER</u>
1419	5420	DB-13620	H-13620
1432	* 1	* 1	* 1
1482	2410	DA-10375	A-10375
1483	2450	N/A	D-10375
1484	2420	DB-10375	H-10375
1485	2430	DL-10375	K-10375
1601	3410	DA-11400	A-11400
1602	3450	N/A	D-11400
1603	3420	DB-11400	H-11400
1604	3430	DL-11400	K-11400
1605	4312	DJ-12800	B-12800
1607	4321	DE-12800	I-12800
1608	4631	DC-12500	J-12500
1707	* 1	* 1	* 1
1752	5212	DJ-14078	B-14078
1753	5251	N/A	E-14078
1754	5221	DE-14078	I-14078
1755	5231	DC-14078	J-14078
1781	6512	DJ-15950	B-15950
1782	6551	N/A	E-15950
1783	6521	DE-15950	I-15950
1784	6531	DC-15950	J-15950

\* 1 - Cross reference has not been verified. If possible, get rib structure and anvil diameter.

**WAGNER INDUSTRIES INC.  
ANVIL COVER  
CROSS REFERENCE CHART**

<u>SAUER</u>	<u>C.U.E.</u>	<u>DOVEY</u>	<u>WAGNER</u>
1818	* 1	* 1	* 1
1844	5212	DJ-14078	B-14078
1845	5251	N/A	E-14078
1846	5221	DE-14078	I-14078
1847	5231	DC-14078	J-14078
1855	N/A	N/A	I-11690
1860	5512	N/A	E-13510
1861	5551	N/A	E-13510
1862	5521	DE-13510	I-13510
1863	5530	DL-13510	K-13510
1912	4512	DJ-11950	B-11950
1913	4551	N/A	E-11960
1914	4521	DE-11950	I-11950
1915	4531	DC-11950	J-11950
1934	2210	DA-10625	A-10625
1935	2250	N/A	D-10625
1936	2220	DB-10625	H-10625
1937	2230	DL-10625	K-10625
2085	5212	DJ-14078	B-14078
2086	5251	N/A	E-14078
2087	5221	DE-14078	I-14078
2088	5231	DC-14078	J-14078
2108	5550	N/A	D-13510
2109	5521	DE-13510	I-13510
2110	5531	DC-13510	J-13510
2123	2210	DA-10625	A-10625

\* 1 - Cross reference has not been verified. If possible, get rib structure and anvil diameter.

**WAGNER INDUSTRIES INC.  
ANVIL COVER  
CROSS REFERENCE CHART**

<u>SAUER</u>	<u>C.U.E.</u>	<u>DOVEY</u>	<u>WAGNER</u>
2440	* 1	* 1	* 1
2442	2210	DA-10625	A-10625
2443	2250	N/A	D-10625
2444	2220	DB-10625	H-10625
2505	5221	DE-14078	I-14078
2832	4621	DE-12500	I-12500
2856	3320	DB-11000	H-11000
2907	5612	DJ-13270	B-13270
2912	6912	DJ-15000	B-15000
2930	6112	DJ-16173	B-16173
2931	6121	DE-16173	I-16173
2967	2110	DA-10860	A-10750
2987	8220	DB-10250	H-10250
3696	2651	N/A	E-10625
3697	2220	DB-10625	H-10625
3698	N/A	N/A	K-10625
4310	3310	DA-11000	A-11000
4862	2120	DB-10860	H-10860
4885	3220	DB-11280	H-11280
4993	1151	N/A	F-8210
5106	6321	DE-15250	I-15250
5111	N/A	N/A	A-10780
5133	N/A	N/A	N-10650
5135	5325	* 1	* 1

\* 1 - Cross reference has not been verified. If possible, get rib structure and anvil diameter.

**WAGNER INDUSTRIES INC.  
ANVIL COVER  
CROSS REFERENCE CHART**

<u>SAUER</u>	<u>C.U.E.</u>	<u>DOVEY</u>	<u>WAGNER</u>
5253	6221	DE-15534	I-15534
5274	6221	DE-15534	I-15534
5333	2525	N/A	N/A
5467	5312	DJ-13812	B-13812
5469	5321	DE-13812	I-13812
5498	10321	DE-18375	I-18375
5512	13125		
5576	10412	DJ-17185	B-17185
5582	12125	N/A	P-9154
6085	* 1	* 1	* 1
6192	14125	N/A	O-10650
6289	N/A	N/A	T-10650
6338	8510	DA-9812	A-9812
6339	8550	N/A	D-9812
6340	8520	DB-9812	H-9812
6341	8530	DL-9812	K-9812
6420	6321	DE-15250	I-15250
6438	2110	DA-10860	A-10860
6510	N/A	N/A	A-15950
6683	3410	DA-11400	A-11400
6684	3450	N/A	D-11400
6685	3420	DB-11400	H-11400

\* 1 - Cross reference has not been verified. If possible, get rib structure and anvil diameter.

**WAGNER INDUSTRIES INC.  
ANVIL COVER  
CROSS REFERENCE CHART**

<u>SAUER</u>	<u>C.U.E.</u>	<u>DOVEY</u>	<u>WAGNER</u>
6710	8430	DL-8720	K-8720
6718	8410	DA-8720	A-8720
6895	12225	N/A	P-8750
6932	46112	DJ-12600	B-12600
6938	N/A	N/A	A-10960
7035	5451	N/A	E-13620
7036	5450	N/A	D-13620
7038	5531	DC-13510	J-13510
7142	1310	DA-8000	A-8000
7249	N/A	N/A	M-12560
7438	* 1	* 1	* 1
7605	10921	DE-18670	I-18670
7656	8650	N/A	D-8790
7668	6621	DE-15340	I-15340
7874	46121	DE-12600	I-12600
7998	8750	N/A	D-8500
7999	N/A	N/A	H-8500
8669	N/A	N/A	P-9500
10523	N/A	N/A	P-9500

\* 1 - Cross reference has not been verified. If possible, get rib structure and anvil diameter.

NOTE: Some numbers have been verified and crossed to WI numbers with only one alternate source. If you find a competitor number that we are missing please send to us so we can add on next update.